

CB10 SportBuds




Models: GDI-EXCB10...19

User Guide

Control Button & Operations



Play / Pause / Answer

Press  once to pause & play song tracks and to answer incoming mobile calls & end calls.

NOTE: The Microphone is located on the back side of the on-wire controller.

Track Selection


Double-click  to advance the track selection.

Triple-click  for previous track selection.


CAUTION: Prolonged use of earphones at high volume may cause irreparable hearing loss. We strongly advise you to adjust your SportBuds volume to a reasonable level. The higher the volume for a prolonged time, the higher the risk of damaging your hearing.

Use your CB10 SportBuds responsibly! It is dangerous, and even illegal in some areas, to use earphones in situations that require your full attention, such as driving a car or motorcycle, riding a bicycle, and crossing a street.

WARNING: The mating connection with your media player may not be waterproof. Do **NOT** connect if wet.



Specifications



Unit Weight

2 ounces

Output Power

<100mW

Frequency Range

20Hz-20,000Hz

Maximum Storage Temperature

105°F / 40.6°C

Waterproof Rating

IPX5

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: reorient or relocate the receiving antenna, increase the separation between the equipment and receiver, connect the equipment into an outlet on a circuit different from that to which the receiver is connected, consult the dealer or an experienced radio/TV technician for help.

RF WARNING STATEMENT:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

IC STATEMENT:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- 1) This device may not cause interference, and
- 2) This device must accept any interference, including interference that may cause undesired operation of the device.

PRODUCT USE AND PROTECTION:

Read and follow all instructions. Use only as intended.

The ECOXGEAR earphones are intended to be used indoors or outdoors. The earphones have been tested to IPX5 waterproofing standards, which means that they are sweatproof. However, the unit is **NOT** waterproof.

To prevent fire or shock, do **NOT** attempt to connect with your media player if unit is damp.

SAFETY ADVISORY & WARNING:

Read and follow all instructions. Use only as intended.

- CAUTION: Do **NOT** open to repair. A qualified technician must carry out repair work.
- ATTENTION: Make sure the 3.5mm auxiliary jack is dry **BEFORE** plugging it into your media player. Failure to do so may result in electrical damage to the unit and may void the warranty.
- WARNING: This product may contain chemicals listed in Proposition 65 (www.oehha.ca.gov/prop65/prop65_list/Newlist.html)
- WARNING: Danger of explosion if battery is incorrectly replaced.
- ATTENTION: Do **NOT** dispose of in a landfill. Contact Grace Digital at www.gracesupport.com or a certified recycling agent to dispose of the unit.

SAFETY:

This product has a limited life span of use and should be replaced when it shows obvious signs of wear.

Do not modify or remove any original component parts of the earphones.

Please exercise care and good judgment when using your ECOXGEAR earphones. Always ensure that you can hear and be aware of any potential hazards around you.

You should always

- 1) Properly clean the ECOXGEAR prior to storage.

You should never

- 1) Never use your ECOXGEAR if you suspect water has entered the device. Using a device with water inside could be potentially hazardous and cause fire or a spark.
- 2) Never use your ECOXGEAR in a wet environment.
- 3) Never attempt to fix, repair your ECOXGEAR unit. Please send it back to Grace Digital for any assessments and repairs.

CARE, MAINTENANCE, & PRECAUTIONS:

- 1) If the unit is placed in water, water may enter into the unit and void your warranty.
- 2) Do **NOT** use or store the unit in places with high temperature.
- 3) **AVOID** prolonged exposure to ultraviolet radiation (UV sunlight) and strong magnetic fields.
- 4) Periodically clean the rubber earbuds with a soft moist cloth and ensure no objects such as dirt, hair, or sand are on the rubber earbuds. Do **NOT** use any oily solvent or chemicals for cleaning.

LIMITED MANUFACTURER'S WARRANTY:

The CB10 is covered by a 3 year limited warranty that covers defects in workmanship and / or materials for a period of 3 years from original purchase date. This warranty does not apply to any products which have been abused, neglected, modified, or used for a purpose other than the one for which they were manufactured. Please refer to the above care and maintenance instructions for suggested care details. The warranty is valid only for the original owner who purchases the unit from an authorized dealer. Transfers do not qualify for warranty protection. Grace Digital reserves the right to replace any out-of-stock or discontinued product with a comparable product. Discontinued products may not be available for warranty replacement. Any contents are **NOT** covered by the limited manufacturer's warranty. Warranty terms may be revised without notification at the discretion of the manufacturer. Please visit www.ecoxgear.com for additional product & warranty information.



CB10 by ECOXGEAR, a division of Grace Digital Inc., San Diego, California.
Designed and Engineered in the USA. Made in China.

Patent Pending.