Pairing the **Sound**Extreme with Your Remote Control


Before you use your Remote Control for the first time, please follow the steps below.

STEP 1   Pull and remove the plastic tab at the bottom of the Remote Control. Your Remote Control should be paired to your unit. **IF NOT** paired, complete Step 2.

STEP 2   Pair your Remote Control with the SoundExtreme.

a. Connect the SoundExtreme to a 12V power supply. (Refer to **Connecting to 12VDC Power Supply** in the User Guide for details.)

b. Within 15 seconds, **PRESS AND HOLD** the Remote Switch Button **ACC** for 3 seconds. Your Remote Control will be paired with your SoundExtreme.

c. Verify that your remote control works by pressing the LED, Backlit Speakers, Button ☼ ☼ to see if the speakers light up.

If the speakers do not light up, unplug the 12V power supply, then repeat steps 2a to 2c.

Once the remote is paired with the SoundExtreme, it will remain stored in the SoundExtreme's memory and should not need to be paired again.